



Sputnik

Trawl Doors

www.hampidjan.is

Connecting and Angle of Attack

When connecting towing wire and backstops to the doors, we recommend to start with just less than medium option.

1. Towing wire.

We recommend to start connecting to F 2.

2. Backstops.

We recommend to start connecting to A or B 2 and D 2.

3. Angle of Attack.

To increase spread, connect to higher numbers.

To decrease spread, connect to lower numbers.

If towing wire is moved from F 2 to F 3, the Angle of Attack will increase by approx. 4 - 5°. If backstops are moved from holes 1 to 2, the Angle of Attack will increase by approx. 2 - 3°.

4. Shallow water fishing at normal speeds.

We recommend to use A and C for shallow water fishing. Minimum weight should be used. As few extra weight plates as possible.

5. Deep water fishing.

We recommend to use B and D for deep water fishing. More weight should be used.

