



# Sputnik

Trawl Doors

[www.hampidjan.is](http://www.hampidjan.is)

## Connecting and Angle of Attack

Suggestions specially focused for high speed surface fishing.

When connecting towing wire and backstops to the doors, we recommend to start with just less than medium options.

1. Towing wire.

We recommend to start connecting to F 2.

2. Backstops.

We recommend to start connecting to A or B 2 and D 2.

3. Angle of Attack.

To increase spread, connect to higher numbers.

To decrease spread, connect to lower numbers.

If towing wire is moved from F 2 to F 3, the Angle of Attack will increase by approx. 2 - 3°.

If backstops are moved from holes 1 to 2, the Angle of Attack will increase by approx. 2°.

4. Surface fishing.

Use equal long backstops, but connect the upper backstops in hole A 1, while the lower backstops are connected in hole D 2 or D 3. The doors will lean downwards and the risk of the doors coming up to the surface is reduced.

5. Close to bottom fishing.

Same length of back stops. Lower back stops in hole D 1 or D 2, but upper back stops in hole A 3 or A 4.

